

Operation & Maintenance Manual.

Horizontal Sliders.



A slim and versatile horizontal sliding system that provides easy access for cleaning and ventilation, it is suitable for treating most window types. Available with 2, 3, 4 or 5 sliding sashes (panels).

Operating Instructions

To open the panels the push button must be released, this will then allow the panels to slide freely in the tracks.

Take care not to slam the panels or push them too fast. To open and close the panels a smooth and even movement is recommended.

It is advised to use two hands to move the panels. This will ensure the panels slide smoothly and do not foul in the track.

To close and secure the panels slide the panels to the closed position.

To remove the panels from the outer frame lift the panel up into the head and lift forward to clear the bottom of the outerframe. Reverse the procedure to replace the panel into the outerframe.

Please note: for frames of 20kg or higher, standard manual handling practices should apply. Glass suckers should be used if available or, failing that, a second person should be consulted to help lift the frame.

Maintenance


There are no special maintenance requirements other than periodic cleaning as all moving parts are factory sealed with lubricant before assembly.

Environmental issues will dictate the cleaning cycle, i.e. location, weather, traffic etc. and should consist of washing down the glass and aluminium frames with a non-alkaline detergent in warm water using a soft cloth or a sponge.


Avoid abrasive cleaners, steel wool, strong acids or alkalis. After cleaning it is advisable to rinse the surface with clean water and wipe dry.

Chips or scratches in the paint finish can be touched up by using a nitro cellulose lacquer paint, but care must be taken to prevent paint from getting into draught seals or moving parts.


HS2 2 Panel



HS3 3 Panel



HS4 4 Panel



HS5 5 Panel

