

Operation & Maintenance Manual.

Lift Out (LO).



A removable secondary glazing panel within its own outer frame, which fixes to the face or reveal of the existing primary window. An ideal solution when only occasional cleaning access is required.

Operating Instructions

To remove the panel from the outerframe lift up into the head and lift panel forward to clear the bottom of the outerframe.

Reverse the procedure to replace the panel in the outerframe. To prevent the panel falling, please ensure the panel is secure in the outerframe.

Please note: for frames of 20kg or higher, standard manual handling practices should apply. Glass suckers should be used if available or, failing that, a second person should be consulted to help lift the frame.

Maintenance

There are no special maintenance requirements other than periodic cleaning as all moving parts are factory sealed with lubricant before assembly.

Environmental issues will dictate the cleaning cycle, i.e. location, weather, traffic etc. and should consist of washing down the glass and aluminium frames with a non-alkaline detergent in warm water using a soft cloth or a sponge.

Avoid abrasive cleaners, steel wool, strong acids or alkalis. After cleaning it is advisable to rinse the surface with clean water and wipe dry.

Chips or scratches in the paint finish can be touched up by using a nitro cellulose lacquer paint, but care must be taken to prevent paint from getting into draught seals or moving parts.

LO

